

HOW TO PROGRAM YOUR DIGITAL TIMER

First thing you want to do to program your timer is to set the date and time.

- To do this flip the lid with a flat edged object
- Push the day button until the correct day shows up at the bottom of screen, do the same for the time.
- Next you either shut the lid or you push the button that the lid will press on when you shut it
- Open the lid again, there should be an indicator in the top right corner that says "ON" if it says "OFF" shut lid again and open or press the button at the very bottom that the lid will press when you shut it. Press the program button.
- You now want to set the date and times in the program mode
- To do this press the day button until all days of the week are present at the bottom of the screen
- Set the program time to 0:00 and push program
- Set the time again to 0:20 and push program
- You will now be in program #2 or on the screen P2
- Set the days of the week so that all days are highlighted again
- Set time to 4:00 and press program
- Set next time to 4:20 and press program
- Set days of the week so that all days are on the screen
- Set time to 8:00 push program
- Set the following time to 8:20 push program
- Make sure all the days of the week are present
- Set time to 12:00 push program
- Set following time to 12:20 push program
- Make sure days of the week are all present
- Set time to 16:00 push program
- Set following time to 16:20 press program
- Set days of the week
- Set time to 20:00 press program
- Set following time to 20:20 you will now have completed program 6 or P6 in the bottom right corner
- Push program twice in the P7 we don't need to set a time here
- You can check to make sure that the times are set so that every 4 hours the timer will come on for 20 minutes by pressing the program button, continue pushing program button to advance through the times you have set
- You are now done programming the timer